

2009 Spa Cafe Building Installation **Instructions and Dimensions**

Please ensure the building is located to allow for adequate clearance. The base should be sufficient to take the weight of the building and the accompanying spa (see separate sheet for spa installation instructions) The base should also be of adequate strength to anchor the building against wind uplift. We recommend that your base should be a minimum of 5" (12.7cm) reinforced concrete

Please ensure that the base is 1" (2.5cm) bigger than the dimensions of the building, but please also allow for the roof overhang. Please refer to the following diagram for measurements.

View of Spa Cafe

